



Make	Model	Year	Recommended	Make
HONDA	ACCORD	1994-2009	55D23L	HONDA
HONDA	ACCORD	2010	55D23L	HONDA
Honda	Accord	1985-1993	NS60R	Honda
Honda	Accord – 2.4 Vti	2008-on	NS60L	Honda
Honda	Accord – 3.5 V6	2008-on	55D23L	Honda
Honda	Accord – Euro	2003-07	NS60L	Honda
Honda	Accord – V6	2008-on	NS70L	Honda
Honda	Accord – Vti	1999-03	NS70R	Honda
Honda	Accord – Vti	2005-07	NS60L	Honda
Honda	Accord 2.3L	1998-2003	NS60R	Honda
Honda	Accord 2.4L Euro	2003-	NS40L	Honda
Honda	Accord 3.0L V6	2006-2007	55D23L	Honda
HONDA	ACCORD COUPE (USED IMPORT)	1990 - 1993	85R	HONDA
HONDA	ACCORD COUPE (USED IMPORT)	1994 - 1997	85L	HONDA
Honda	Accord Euro Sedan and Tourer	2008-on	NS60L	Honda
Honda	Accord LXI/VTI-L/VTI V6/VTI-L V6	2003-	NS60R	Honda
HONDA	ACCORD SEDAN (USED IMPORT)	1989 - 1993	NS70R	HONDA
HONDA	ACCORD SEDAN (USED IMPORT)	1993 – 1997	85L	HONDA
HONDA	ACCORD TORNEO (USED IMPORT)	1997 -	85L	HONDA
HONDA	ACCORD V6	2003	NS60L	HONDA
HONDA	ACCORD VIGOR 2000 (USED IMPORT)	1985 -	NS60R	HONDA
HONDA	ACCORD WAGON (USED IMPORT)	1991 - 1993	85R	HONDA
HONDA	ACCORD WAGON (USED IMPORT)	1994 - 1997	85L	HONDA
Honda	Accord/Torneo	2001-on	85L	Honda
HONDA	ACTY 660 (USED IMPORT)	1990 - 1997	NS40R	HONDA
Honda	Ascot (Used Import)	1989-1995	85R	Honda
Honda	Ascot and Rafaga (Used Import)	1994-1998	NS70R	Honda
HONDA	ASCOT INNOVA	1992 - 1996	NS70R	HONDA
Honda	City	2009-on	NS60R	Honda
HONDA	CITY PRO	ALL YEARS	NS60R	HONDA
HONDA	CITY VAN	ALL YEARS	NS40R	HONDA
HONDA	CIVIC	1985 -	NS60R	HONDA
Honda	Civic – 3DR / 4DR / 5DR / Coupe / VTiR - Coupe	1988-2007	NS60R	Honda
Honda	Civic 1.3 Hybrid	1996-2007	NS40R	Honda
Honda	Civic 1.6L GT/I Hatchback/Sedan/LX/Lxi	1989-1997	NS60R	Honda
HONDA	CIVIC SEDAN (NZ ONLY)	2006	NS40R	HONDA
Honda	Civic Type R	2007-on	NS60L	Honda
HONDA	CONCERTO	1988 - 1993	NS60R	HONDA
HONDA	CONCERTO (USED IMPORT)	1988 - 1993	NS60L	HONDA
HONDA	CROSSROAD	1994 - 1997	NS60R	HONDA
HONDA	CRV	1997 - 2002	NS60R	HONDA
HONDA	CRV	2002 -	NS60L	HONDA
HONDA	CRX	1992 - 1996	NS40L	HONDA
HONDA	DOMANI	1992 - 1998	NS40R	HONDA
Honda	Fit	2001-on	NS40L	Honda
HONDA	HORIZON	1994 - 1998	NS60R	HONDA
HONDA	HORIZON DIESEL	1994 - 1997	NS70R	HONDA
HONDA	HRV	1999 -	NS60L	HONDA
Honda	HR-V (Used Import)	1999-	NS40L	Honda
Honda	HRV 4WD, HRV SPORT	1999-	NS60L	Honda
HONDA	INSIGHT	2001 -	NS40R	HONDA
Honda	Inspire	2001-on	NS70L	Honda
Honda	Inspire - Saber (Used Import)	1996-	NS70R	Honda



HONDA	<i>INSPIRE (USED IMPORT)</i>	2001 -	NS70R	HONDA
HONDA	<i>INSPIRE VIGOR</i>	1990 - 1995	85R	HONDA
HONDA	INTEGRA	1994 - 2001	NS60R	HONDA
Honda	Integra – Base and Type R	2002-	NS60L	Honda
Honda	Integra – Gsi, VTiR, Type R	1994-01	NS60R	Honda
Honda	Integra – LS	1990-93	55D23R	Honda
HONDA	INTEGRA 1.5L 1.6L (USED IMPORT - NZ ONLY)	1986 T-1997	NS60R	HONDA
HONDA	<i>INTEGRA GSI VTI-R VTI TYPE R</i>	1991 - 1994	NS70R	HONDA
HONDA	INTEGRA VTI-R & TYPE S	2002 - 2005	NS60L	HONDA
HONDA	JAZZ	1988 - 1996	NS60L	HONDA
HONDA	JAZZ	2002 -	NS40L	HONDA
HONDA	JAZZ (USED IMPORT)	1996 - 1998	NS60L	HONDA
Honda	Legend	1988-	NS70R	Honda
HONDA	LEGEND 2.0L	1985 - 1990	85R	HONDA
Honda	Legend 2.0L (Used Import)	1985-1990	85R	Honda
Honda	Legend 2.5/2.7 (Used Import)	1985-1990	NS70L	Honda
HONDA	LEGEND 3.2L 3.5L	1990 - 1999	NS70R	HONDA
Honda	Legend 4DR and Coupe	1991-07	NS70L	Honda
HONDA	LEGEND V6	CURRENT	NS70L	HONDA
HONDA	LOGO	1999 -	55D23L	HONDA
Honda	MDX	2003-06	NS70L	Honda
Honda	<i>MDX 3.5L V6 4WD</i>	2003-2005	55D23L	Honda
HONDA	NSX	1991 - 2000	NS70R	HONDA
HONDA	NSX	2003	NS70L	HONDA
HONDA	NSX 3000 (USED IMPORT)	1990 - 1995	NS70L	HONDA
Honda	NSX MT and AT	1991-94	55D23L	Honda
Honda	NSX MT and AT	1995-2004	NS70L	Honda
HONDA	ODYSSEY	CURRENT	NS60L	HONDA
HONDA	ODYSSEY	2001 - 2004	NS60R	HONDA
HONDA	ODYSSEY	2007 - 2009	NS60L	HONDA
Honda	Odyssey – V6	2000-on	55D23R	Honda
Honda	Odyssey 6 and 7 Seater	1995-99	55D23L	Honda
Honda	Odyssey L4	2000-07	NS60L	Honda
Honda	Odyssey VTEC	2001-2003	NS60L	Honda
HONDA	ODYSSEY WAGON	1995 - 2000	55D23L	HONDA
HONDA	ODYSSEY WAGON	2001 - 2005	NS60L	HONDA
HONDA	ORTHIA (USED IMPORT)	1996 -	85R	HONDA
HONDA	PARTNER	1996 - 1999	NS40R	HONDA
HONDA	PRELUDE	1992 - 1996	55D23L	HONDA
HONDA	PRELUDE	1997 - 2000	NS60L	HONDA
Honda	Prelude – ATTS	1997-01	NS70L	Honda
Honda	Prelude – S	1992-97	NS60L	Honda
Honda	<i>Prelude – VTiR</i>	1994-on	NS70L	Honda
Honda	Prelude (Auto)	1997-2000	NS70L	Honda
HONDA	PRELUDE (USED IMPORT)	1997 -	85R	HONDA
HONDA	PRELUDE 2.1 2.2 (USED IMPORT)	1991 - 1996	85R	HONDA
HONDA	QUINT	1980 - 1995	NS40R	HONDA
HONDA	RAFARGA	1993 - 1995	NS70R	HONDA
HONDA	S2000	1999 -	NS60L	HONDA
HONDA	SABER	1995 - 1997	NS70R	HONDA
HONDA	SHUTTLE	1984 - 1995	55D23L	HONDA
Honda	Shuttle	1998-on	NS60R	Honda
HONDA	VIGOR	1985 - 1995	NS40R	HONDA

Please verify your battery size and terminal layout with the data provided on this website to ensure correct battery layout.