



Make	Model	Year	Recommended	Upgrade
JAGUAR	DAIMLER 3.6 4.0	1987 -	DIN55L	
JAGUAR	S TYPE	1999 -	DIN85L	
Jaguar	S Type R	2002--05	DIN100L	
JAGUAR	SOVEREIGN 3.6	1987 TO 1989	85R	
JAGUAR	SOVEREIGN 4.0	1990 TO 1994	DIN85L	
JAGUAR	X TYPE	2009-	DIN66L	DIN77L
JAGUAR	X TYPE 2.1 LITRE	2004 TO 2006	DIN55L	
Jaguar	X Type 2.5 V6	2001-05	DIN77L	
JAGUAR	X TYPE 3 LITRE	2004 -	DIN85L	
Jaguar	XF XJ DIESEL & PETROL	2008-on	DIN85L	DIN100L
Jaguar	XJ	2004-on	DIN85L	
Jaguar	XJ 12	1995-on	DIN85L	
Jaguar	XJ 40 (Xjs, XJ6) all include Sovereign	1987-94	DIN55L	
Jaguar	XJ Sovereign	1997-03	DIN85L	
Jaguar	XJ V6 and V8	2007-on	DIN85L	
JAGUAR	XJ12	1985 TO 1987	85R	
JAGUAR	XJ40	1987 TO 1994	DIN55L	
Jaguar	XJ6	1995-on	DIN85L	
Jaguar	XJ6 & Sovereign	1987-1994	DIN55L	
Jaguar	XJ6 & XJ8	2004-2006	DIN85L	
Jaguar	XJ6 / Sovereign	1997-2000	DIN85L	
Jaguar	XJ6 / Sovereign / V12 (in boot)	1994-1997	DIN85L	
Jaguar	XJ6 all include Sovereign	1972-87	85R	
JAGUAR	XJ6 DIESEL	CURRENT	DIN77L	DIN85L
Jaguar	XJ6 V12	1972-87	NS70R	
JAGUAR	XJ6 / XJ6 SOVEREIGN	1987 TO 1997	DIN55L	DIN66L
Jaguar	XJ6, XJR, XJ12	1994-on	DIN85L	
JAGUAR	XJ8	1998 -	DIN85L	
Jaguar	XJ8 3.2, 4.0 Sport	2001-on	DIN85L	
JAGUAR	XJR	1995 TO 2001	DIN66L	
JAGUAR	XJS	1977 TO 1996	DIN55L	
Jaguar	XJS V12	1991-1995	DIN66L	
JAGUAR	XK	2004-	DIN77L	DIN85L
Jaguar	XK and XKR	2007-on	DIN85L	
JAGUAR	XK8	1995 -	DIN85L	
JAGUAR	XKR	1998 -	DIN85L	

Please verify your battery size and terminal layout with the data provided on this website to ensure correct battery layout.