



TOYOTA

Make	Model	Year	Recommended battery type	Quantity
TOYOTA	4 RUNNER	1989 TO 1996	55D23R	
TOYOTA	4 RUNNER – DIESEL	1990 -	NS70R	
TOYOTA	ALTEZA	1999 -	NS40L	
Toyota	Altezza Gita 3.0L straight 6	2002-on	55D23L	
Toyota	Altise	2003-on	55D23L	
TOYOTA	ARISTO	1991 TO 1997	85L	
Toyota	Ascent	2000-on	NS40L	
TOYOTA	AURION	2007 -	55D23L	
TOYOTA	AVALON	2000 TO 2007	55D23L	
TOYOTA	AVENSIS	2000 -	55D23L	
TOYOTA	AVENSIS TOURER	2009	NS60L	
TOYOTA	CALDINA	1992 TO 1998	NS40L	
TOYOTA	CAMRY	1993 - 2008	55D23L	
TOYOTA	CAMRY HYBRID	2010	55D23L	
TOYOTA	CAMRY VISTA (USED IMPORT)	1990 -	NS40L	
Toyota	Camry Wagon	2000-on	55D23L	
TOYOTA	CARIB 4WD	1995 TO 1998	55D23L	
TOYOTA	CARINA	1990 TO 1996	NS40L	
TOYOTA	CAVALIER	1996 -	85L	
TOYOTA	CELICA	1994 TO 2000	55D23L	
TOYOTA	CELICA	2001 -	NS60L	
TOYOTA	CELICA 1.6 1.8 2.1 (USED IMPORT)	1977 TO 1994	NS60L	
TOYOTA	CELICA 2.0 4WD/TURBO (USED IMPORT)	1989 TO 1993	55D23L	
TOYOTA	CELICA LIFTBACK 4 WD TURBO & SX	1990 TO 1994	85L	
TOYOTA	COROLLA	1992 TO 2005	NS40L	
TOYOTA	COROLLA	2005 -	NS60L	
TOYOTA	COROLLA ASCENT CONQUEST LEVIN ULTIMA	2010	NS40L	
Toyota	Corolla Diesel Hatch	2008-on	N70L	
Toyota	Corolla GX and GLX	2007-on	NS40L	
TOYOTA	COROLLA LEVIN & SPRINTER TRUENO (USED IMPORT)	1993 TO 1997	NS40L	
TOYOTA	COROLLA SPORTIVO	2003-	NS60L	
TOYOTA	CORONA	1993 TO 1996	NS60L	
Toyota	Cressida	1994-on	55D23L	
Toyota	Crests – custom	1990-on	55D23L	
TOYOTA	CROWN (USED IMPORT)	1993 -	85L	
TOYOTA	CURREN (USED IMPORT)	1994 TO 1997	NS60R	
TOYOTA	CYNOS (USED IMPORT)	1992 TO 1994	NS40R	
TOYOTA	ECHO	1999 -	NS40R	



TOYOTA

TOYOTA	EMINA & LUCIDA (USED IMPORT) DIESEL & PETROL	1990 TO 1996	NS70R	
Toyota	Estima	2001-on	NS70R	
TOYOTA	ESTIMA & PREVIA 2400 (USED IMPORT)	1990 TO 1995	NS40L	
TOYOTA	GRANVIER	1995 TO 1999	55D23L	
TOYOTA	HARRIER	1997 TO 1999	55D23L	
TOYOTA	HI ACE	1974 TO 1996	85R	
TOYOTA	HI ACE	1997 -	55D23R	
TOYOTA	HI ACE – DIESEL	1980 TO 1998	NS70R	
TOYOTA	HI ACE – DIESEL	1999 TO 2009	N70R	
TOYOTA	HI ACE – DIESEL	2010	NS70L	
TOYOTA	HI LUX	1984 TO 2004	55D23L	
TOYOTA	HI LUX	2005 TO 2009	NS70L	
TOYOTA	HI LUX	2010	55D23L	
TOYOTA	HI LUX – DIESEL	1984 TO 1998	NS70R	
TOYOTA	HI LUX – DIESEL	1999 -	N70L	
Toyota	Hi Lux – V6 Petrol	2008-on	N70L	
TOYOTA	HI LUX SURF (USED IMPORT) – DIESEL	1990 TO 1996	NS70R	
Toyota	Highlander	2004-on	NS70R	
TOYOTA	IPSUM	1996 TO 2000	NS60L	
Toyota	Ipsum	2001-on	85L	
TOYOTA	KLUGER	2004 TO 2009	NS70L	
TOYOTA	KLUGER	2010	55D23L	
Toyota	Land Cruiser 200 VX and VX LTD	2007-on	N70L	
Toyota	Landcruiser – Diesel	1974-95	N70R	
Toyota	Landcruiser – Diesel Series 100	1998-01	N70L	
Toyota	Landcruiser – FZJ-105R series	1999-on	NS70L	
Toyota	Landcruiser – HDJ-100R Turbo Diesel	2001-on	NS70R	
Toyota	Landcruiser – HDJ-80R Turbo Diesel	1991-on	NS60R	
Toyota	Landcruiser – HZJ 105 series	2000-on	N70R	
Toyota	Landcruiser – Muster, Ltd. Edition	2004-on	N70R	
Toyota	Landcruiser – Petrol Series 100/105	1997-on	NS70L	
Toyota	Landcruiser – Petrol V8	1998-on	N70L	
TOYOTA	LANDCRUISER 100 SERIES – DIESEL	1998 -	N70L	2 BATTERIES
Toyota	Landcruiser 200 Series V8 Turbo Diesel	2007-on	NS70R	
TOYOTA	LANDCRUISER 70 SERIES	1985 TO 1994	N70R	
TOYOTA	LANDCRUISER 70 SERIES	1995 TO 2000	N70L	
TOYOTA	LANDCRUISER 78 SERIES	2003 -	NS70R	



TOYOTA

TOYOTA	LANDCRUISER 80 SERIES	1990 TO 1998	N70L	
TOYOTA	LANDCRUISER GXL - DIESEL & PETROL	2010	N70L	
Toyota	Landcruiser Prado	2003-2006	N70L	
Toyota	Landcruiser Prado	2006-on	55D23L	
Toyota	Levin – Corolla	1999-on	NS40L	
TOYOTA	LITE ACE – DIESEL	1981 TO 1996	NS70R	
TOYOTA	LITE ACE & TOWN ACE (USED IMPORT)	1990 TO 1995	NS40L	
TOYOTA	MASTER ACE	1982 TO 1996	NS60L	
TOYOTA	MR2	1985 -	55D23L	
TOYOTA	MR2 1600 (USED IMPORT)	1992 TO 1997	NS40L	
TOYOTA	MR2 2000 (USED IMPORT)	1989 TO 1997	85L	
TOYOTA	MR2 SPYDER	2001 -	NS60L	
Toyota	NRX Coupe	1983-on	NS60L	
TOYOTA	PASEO	1991 TO 1999	85R	
TOYOTA	PICNIC	1999 -	55D23L	
TOYOTA	PRADO	1996 TO 2000	55D23L	
TOYOTA	PRADO	2000 TO 2002	N70R	
TOYOTA	PRADO	2003 -	NS70R	
TOYOTA	PRADO – DIESEL	2006 -	N70L	
Toyota	Previa	2000-on	55D23L	
TOYOTA	PREVIA MPV	1990 TO 1999	NS60L	
Toyota	Prius	2001-on	NS40L	
Toyota	Rav 4	2000-2006	NS60R	
TOYOTA	RAV4	1994 TO 1998	NS40R	
Toyota	RAV4	2003-05	55D23R	
Toyota	RAV4	2005-on	55D23L	
TOYOTA	RAV4 (NZ ONLY) – DIESEL	2008	N70L	
TOYOTA	RAV4 CRUISER AWD	2003	NS60R	
Toyota	RAV4 CV6	2007-on	NS70L	
TOYOTA	SAHARA - DIESEL & PETROL	2003 -	N70R	
TOYOTA	SCEPTER (USED IMPORT)	1993 TO 1997	NS40L	
TOYOTA	SERA (USED IMPORT)	1992 TO 1995	NS40L	
TOYOTA	SOARER	1994 -	NS70L	
TOYOTA	SOARER (USED IMPORT)	1991 TO 1998	85L	
Toyota	Solara	2003-on	55D23L	
TOYOTA	SPACIA VAN	1996-	NS40L	
TOYOTA	SPACIO	1998 -	55D23L	
TOYOTA	SPRINTER (USED IMPORT)	1992 TO 1995	NS60L	
TOYOTA	SPRINTER CARIB (USED IMPORT)	1988 TO 1995	NS40L	
TOYOTA	SPRINTER MARINO & COROLLA CERES (USED IMPORT)	1993 TO 1996	NS60L	
TOYOTA	SR 5	1999	N70R	
TOYOTA	STARLET DX XI S	1986 TO 1996	NS60L	



TOYOTA

TOYOTA	STARLET S GL XL	1997 TO 1999	NS60R	
TOYOTA	SUPRA (USED IMPORT)	1986 TO 1997	85L	
TOYOTA	SURF	1995 -	55D23R	
TOYOTA	TARAGO	ALL YEARS	55D23L	
Toyota	Town Ace	1997-on	NS40L	
TOYOTA	TOWN ACE 1.8L 2.0L	1992 TO 1998	NS40R	
Toyota	Town Ace SBV	1997-on	NS40L	
Toyota	Town Ace SBV	1992-1997	85R	
TOYOTA	VIENTA	1995 TO 2000	55D23L	
Toyota	Will	2001-	NS40L	
TOYOTA	WINDOM (USED IMPORT)	1991 TO 1995	85L	
TOYOTA	YARIS	2005 -	NS60L	

Please verify your battery size and terminal layout with the data provided on this website to ensure correct battery layout.